



KitchenAid

3,1 L Food Processor 5KFP1319



- **3,1 L large capacity Food Processor**
To prepare any size meal
Simplify large batch meal making
- **Powerful motor and durable blades**
To easily tackle tough chopping, shredding and kneading tasks
- **Illuminated LED-controls with 3 easy-press speed paddles options (high, low and pulse)**
To handle a variety of ingredients with precision
For simple operations
Pulse function allows to control the results and to chop food to the desired texture
- **All-in-one storage caddy**
Stores blades and discs right in the work bowl
Saves space
- **Adjustable ExactSlice slicing disc**
To easily adjust the slicing thickness
- **Dicing kit**
To quickly create consistent, uniform cubes every time
- **Storage/refrigerator lid that fits right on the work bowl**
To keep extra ingredients fresh
- **Stainless steel multipurpose blade, and dough blade**
To chop, mix and purée
To quickly knead dough
- **Reversible fine and medium shredding disc**
To shred cheese, vegetables and more
- **Leak-resistant, snap and go work bowl with latched lid and 3-in-1 wide mouth feed tube**
Simple setup and easy to use
Quick and easy cleaning
To process a variety of ingredient shapes and sizes including large items



EMPIRE RED



ALMOND CREAM



CONTOUR SILVER



ONYX BLACK



MATTE BLACK

KitchenAid 3,1 L Food Processor 5KFP1319

TECHNICAL DATA

Wattage		400 W
Voltage		220 - 240 V
Frequency		50/60 Hz
RPM	Low (1)	750
	Medium (2)	1600
	Pulse	2000
Material base/housing		Textured/polished
Material bowl		Plastic BPA-free (Tritan)
Material multipurpose blade		Stainless steel
Material disc		Stainless steel
Material paddles and knob		Plastic - satin chrome
Product dimensions (with storage lid)	H x W x D	46,4 x 22,2 x 22,2 cm
Packaging dimensions	H x W x D	27,3 x 48,6 x 27 cm
Master pack dimensions	H x W x D	28,5 x 49,6 x 28,1 cm
Net weight		4,54 kg
Gross weight		5,66 kg
Master pack gross weight		6,03 kg
Master pack		1 unit
Cord length (colour)		91,44 cm (black)
Integrated cord wrap (under base)		Yes
Country of origin		China

REFERENCES

COLOURS

EAN

5KFP1319EER	EMPIRE RED	8003437625084
5KPF1319EAC	ALMOND CREAM	8003437625091
5KFP1319ECU	CONTOUR SILVER	8003437625039
5KFP1319EOB	ONYX BLACK	8003437625077
5KFP1319EBM	MATTE BLACK	8003637625053

KitchenAid 3,1 L Food Processor 5KFP1319

STANDARD ACCESSORIES



Multi-purpose blade

To chop, mince or purée cheese, chocolate, fruits, fresh herbs, nuts, tofu and vegetables. To mix pasta sauce, pesto, salsa, sauces, batters and doughs. Made out of stainless steel, dishwasher-safe (top rack only).



Dough blade

To knead yeast doughs quickly and thoroughly. Dishwasher-safe (top rack only).



Reversible fine and medium shredding disc

To shred potatoes, soft vegetables, cabbage, cheese, chocolate, hard fruits and hard vegetables. Dishwasher-safe (top rack only).




External adjustable slicing knob and slicing disc

To easily adjust the slicing thickness, from thin to thick, from the outside, of soft fruits, potatoes, tomatoes, soft vegetables, cheese, chocolate, hard fruits and hard vegetables. Dishwasher-safe (top rack only).



Dicing kit and dicing kit clean out tool

Transform all potatoes, fruits, vegetables and cheese into perfect dices. The dicing clean out tool will help push any extra food through the grid. Dishwasher-safe (top rack only).



Storage/refrigerator lid

Dishwasher-safe (top rack only).



3,1 L BPA-free work bowl with drive pin

Dishwasher-safe (top rack only).

Hinged lid with 3-in-1 wide mouth feed tube and 3-in-1 food pusher

The hinged lid is locked by means of a latch. Sealed lid, leak-resistant work bowl with sealed handle and interlock, rounded edges and smooth finishes. For easier clean-up. Use the small feed tube and pusher to process small or slender items, like single carrots or celery stalks. Use the large feed tube to process larger items. The 3-piece food pusher allows processing a variety of shapes and sizes.

To slowly drizzle oil into ingredients, fill the small pusher with the desired amount of oil. A small hole in the bottom of the pusher will drizzle the oil at a constant rate. For emulsifying sauces and dressings. Dishwasher-safe (top rack only).



Drive adapter (upper and lower)

To use with all blades and discs mounted on the drive pin in the bowl. Dishwasher-safe (top rack only).
